


Active/IPICO UHF Mat/Side Antenna layout proposal V11

To convert from DF to UHF unplug 1A, 2A and 4A and replace it with 1B, 2B and 4B.


A



DF Card/Connector layout and identification

- 1A. DF RX Card Channel 1 – IP2902
- 2A. DF RX Card Channel 2 - IP2902
- 3. Octal – IP2916
- 4A. DF TX card – IP2905
- 5. Power supply - IP 0901-1
- 6. DF TX connectors and Ext power supply IN

B




UHF Card/Connector layout and identification

- 1B. UHF TXRX card – IP2997
- 2B. UHF TXRX card – IP 2997
- 3. Octal – IP2916
- 4B. Blanking plate
- 5. Power supply IP 0901-1
- 6. Ext power supply IN




Caution: Never disconnect UHF antennas/cables when the reader is ON. Switch OFF or put the Quattro cards in SLEEP mode before disconnecting the antennas.

Don't use the reader with only antenna cables connected without connecting the actual antennas.




UHF SE with a narrow-read point (Typical small race)




UHF SE with a wide-read point




Side antenna deployments (in Default mode X)




BUT
 These Configurations
 with 1 side ant
 overlapping 2-7
 mat ants that includes
 mat of the 2nd channel
 are not preferred.




Homepage layout



Sample Home screens






Select correct Race mode via reader front panel keys/menu
Or
in Setting on the reader web page

Change the mode setting according to the reader layout schemes on next page below


Available modes:

- 0 = Default**
- 1 = Primary**
- 2 = Backup**
- 3 = Announce**




**When you have a cluster of 2 readers at a read point always make sure its set to Primary and Backup
Never setup 2 readers that are in the cluster
Primary/Primary or
Backup/Backup combinations**

1. For **small races <1000 runners or Single mat deployments (4-8m wide)** the proposed setup is as follows:



2. For **hi-density/large/Hi-performance races (8m+ wide) typically > 1000 runners** the proposed setup is as follows: (small races can use this as well)



NOTE:

- 1. For 2 reader setup at a read point: ALWAYS set the readers to Primary and Backup with a 5-7m (15-21ft) separation**
- 2. Refer to Side antenna layout for correct deployments.**